

Torsionsfeder-Tabelle für DST

Artikel-Nr.	Federtyp		
R 1 / L 1	50 -	45 -	433
R 2 / L 2	50 -	45 -	473
R 3 / L 3	50 -	48 -	448
R 4 / L 4	50 -	48 -	490
R 5 / L 5	50 -	48 -	536
R 6 / L 6	50 -	48 -	586
R 7 / L 7	50 -	48 -	642
R 8 / L 8	50 -	50 -	497
R 9 / L 9	50 -	50 -	543
R 10 / L 10	50 -	50 -	594
R 11 / L 11	50 -	50 -	650
R 12 / L 12	50 -	50 -	712
R 13 / L 13	50 -	53 -	597
R 14 / L 14	50 -	53 -	654
R 15 / L 15	50 -	53 -	716
R 16 / L 16	50 -	53 -	784
R 17 / L 17	50 -	53 -	858
R 18 / L 18	50 -	56 -	646
R 19 / L 19	50 -	56 -	707
R 20 / L 20	50 -	56 -	775
R 21 / L 21	50 -	56 -	850
R 22 / L 22	50 -	56 -	931
R 23 / L 23	50 -	58 -	696
R 24 / L 24	50 -	58 -	1005
R 25 / L 25	50 -	58 -	1102
R 26 / L 26	50 -	60 -	746
R 27 / L 27	50 -	60 -	818
R 28 / L 28	50 -	60 -	896
R 29 / L 29	50 -	60 -	983
R 30 / L 30	50 -	60 -	1078
R 31 / L 31	50 -	63 -	783
R 32 / L 32	50 -	63 -	858
R 33 / L 33	50 -	63 -	941
R 34 / L 34	50 -	63 -	1032
R 35 / L 35	50 -	63 -	1132
R 36 / L 36	50 -	63 -	1241
R 37 / L 37	50 -	65 -	996
R 38 / L 38	50 -	65 -	1093
R 39 / L 39	50 -	65 -	1199
R 40 / L 40	50 -	65 -	1315
R 41 / L 41	50 -	68 -	1027
R 42 / L 42	50 -	68 -	1127
R 43 / L 43	50 -	68 -	1236
R 44 / L 44	50 -	68 -	1356
R 45 / L 45	50 -	68 -	1489
R 46 / L 46	50 -	70 -	1180
R 47 / L 47	50 -	70 -	1294
R 48 / L 48	50 -	70 -	1420
R 49 / L 49	50 -	70 -	1559
R 50 / L 50	50 -	75 -	1362
R 51 / L 51	50 -	75 -	1495
R 52 / L 52	50 -	75 -	1641